



Avaya Integrated Management Release 3.1

**Enterprise Network Management
Installation and Upgrade**

14-300444
Issue 2
February 2006
Material ID 700385677

© 2006 Avaya Inc.
All Rights Reserved.

Notice

While reasonable efforts were made to ensure that the information in this document was complete and accurate at the time of printing, Avaya Inc. can assume no liability for any errors. Changes and corrections to the information in this document may be incorporated in future releases.

For full legal page information, please see the complete document, Avaya Legal Page for Software Documentation, Document number 03-600758.

To locate this document on the website, simply go to <http://www.avaya.com/support> and search for the document number in the search box.

Documentation disclaimer

Avaya Inc. is not responsible for any modifications, additions, or deletions to the original published version of this documentation unless such modifications, additions, or deletions were performed by Avaya. Customer and/or End User agree to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation to the extent made by the Customer or End User.

Link disclaimer

Avaya Inc. is not responsible for the contents or reliability of any linked Web sites referenced elsewhere within this documentation, and Avaya does not necessarily endorse the products, services, or information described or offered within them. We cannot guarantee that these links will work all of the time and we have no control over the availability of the linked pages.

Warranty

Avaya Inc. provides a limited warranty on this product. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product, while under warranty, is available through the following Web site:

<http://www.avaya.com/support>

Copyright

Except where expressly stated otherwise, the Product is protected by copyright and other laws respecting proprietary rights. Unauthorized reproduction, transfer, and or use can be a criminal, as well as a civil, offense under the applicable law.

Avaya support

Avaya provides a telephone number for you to use to report problems or to ask questions about your product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site:

<http://www.avaya.com/support>

Contents

Chapter 1: Introduction	7
Purpose	7
Prerequisites	7
Intended Audience	7
Conventions Used in This Book	8
Support Resources	8
Avaya Technology and Consulting (ATAC)	8
Communications, Solutions, and Integration (CSI) Group of Software Services	8
Avaya Technical Service Organization (TSO)	9
Avaya Network Management Software Systems Support Group (NMSSS)	9
Customized Management Solutions for Avaya Integrated Management	10
Avaya Contact Information	11
Product Documentation	12
How to Access Books on the Web	12
Tell Us What You Think!	12
Chapter 2: Overview	13
Enterprise Network Management	13
Enterprise Network Management CDs	13
Windows Server Requirements	14
Windows Client PC Requirements	16
Pre-Installation Tasks	17
Integrated Management Server	18
Chapter 3: Network Management Installation	19
Network Management CD	19
Avaya SMON Manager License Key	20
HP OpenView Integration	20
Installing the Software	20
Uninstalling the Software	25
Changing an Application Link on the Avaya Integrated Management Launch Page	26
Chapter 4: Administration Tools Installation	27
Administration Tools CD	27
Installing the Administration Tools	28
Installing OpenSSH SCP Server	30

Contents

Starting Avaya Site Administration	31
Starting Voice Announcement Manager	31
Uninstalling the Administration Tools	31
Uninstalling OpenSSH SCP Server	32
Chapter 5: Network Provisioning Installation	33
Overview of Provisioning and Installation Manager.	33
Pre-Installation Tasks	34
Ensuring Browser Settings Allow Active Scripting	35
Network Provisioning CD	35
Installing the Software	35
Uninstalling the Software	36
Chapter 6: VoIP Monitoring Manager Installation	39
What is Avaya VoIP Monitoring Manager?	39
Avaya VoIP Monitoring Manager Components	40
Avaya VoIP Monitoring Manager Server	40
Avaya VoIP Monitoring Manager RTCP Monitor	40
Avaya VoIP Monitoring Manager Client	40
Avaya VoIP Monitoring Manager Web Client	41
WebLM License Server	41
Pre-Installation Tasks	42
Ensuring Windows SNMP Service is Installed.	43
VoIP Monitoring Manager CD	44
Avaya VoIP Monitoring Manager License Key	44
Microsoft SQL 2000 Database.	44
VoIP Monitoring Manager System Requirements	45
Installing the Software	48
Installing VoIP Monitoring Manager With a Database Already Installed	51
Installing the Client Software	54
Installing VoIP Monitoring Manager Licenses	55
Post-Installation Tasks	56
Checking for a Valid Community Name	56
Configuring the Avaya Communication Manager Administration Forms	57
Configuring the IP Network Region Form	58
Configuring the System Parameters IP-Options Form	59
Configuring the RTCP Listen Port	60
Uninstalling the Software	61

Chapter 7: Avaya Mailbox Manager	63
About Mailbox Manager	63
Launching Mailbox Manager	63
Licensing Mailbox Manager.	64
Appendix A: Legal Information	65
Overview	65
Avaya Network Management Enterprise Server Software	65
Notice	65
Disclaimer	66
Warranty	66
License	66
Copyright.	67
Security and Virus Disclaimer	68
Trademarks.	68
Avaya Provisioning and Installation Manager Software.	69
Notice	69
Disclaimer	69
Warranty	70
License	70
Copyright.	71
Security and Virus Disclaimer	71
Trademarks.	72
Index	73

Chapter 1: Introduction

Purpose

The purpose of this book is to provide the following information:

- Hardware and software requirements for Microsoft® Windows® servers and Windows client PCs.
- Pre-installation tasks that must be completed prior to installation.
- Procedures to install the products in the Avaya Integrated Management, Enterprise Network Management offer. If any of the products included in this offer are already installed on your system, those products will be upgraded during this installation.

Prerequisites

System administrators who install the Enterprise Network Management software should be experienced in installing software on Windows operating systems in a converged network environment.

Intended Audience

This book is written for system administrators who are responsible for installing software on Windows servers and clients.

Conventions Used in This Book

The following typographical conventions are used:

- **Bold** type is used to indicate information that you type, buttons in a window, and the **Enter** key on the keyboard. It is also used for emphasis.
- `Courier` font is used for any information that the computer screen displays.
- Arrows indicate options that you select from cascading menus; for example, “Select File > Open” means choose the “Open” option from the “File” menu.

Support Resources

Avaya provides a variety of planning, consulting, and technical services. The following sections describe the resources and services that are available.

Avaya Technology and Consulting (ATAC)

Avaya Technology and Consulting (ATAC) works with client teams to develop detailed solutions for connectivity to Avaya Communication Manager solutions. The ATAC also designs network configurations.

Communications, Solutions, and Integration (CSI) Group of Software Services

Avaya Communications, Solutions, and Integration (CSI) Group of Software Services offers customers the following services:

- Platform readiness verification
- Remote implementation and installation
- Network management server configuration
- Customer acceptance verification
- Custom on-site services

The CSI Group consists of the following two teams:

- **Converged Solutions Implementation Engineering**

The Converged Solutions Implementation Engineering (CSIE) team implements multi-site media gateway (G350/G650/G700) deployment projects for both voice and data design. The overall direction of the CSIE team is to bring the correct methodology to these complex deployments that span various regions and to provide continuity to the overall project from the voice and data implementation standpoint.

- **Data Network Implementation Engineering (formerly RNIS)**

The Data Network Implementation Engineering team implements and/or upgrades existing or new data networks. This team analyzes the customer's network design requirements and performance expectations, and then creates the hardware and software installation specification used to implement data devices including Cajun, VPN, Wireless LAN, Secure Gateways, Extreme, and multi-vendor data equipment.

The CSI Group provides support on a contract basis. You can purchase various implementation offers from the CSI Group in Tampa, Florida. See [Table 1: Customer-Accessible Resources](#) on page 11 for contact information.

Avaya Technical Service Organization (TSO)

The Avaya Technical Service Organization (TSO) provides support to the Avaya Integrated Management client teams, field technicians, and customers. The TSO will bill customers for support on a time and materials basis if the following conditions exist:

- Customers do not provide remote access.
- Customers do not have a current maintenance agreement.
- Customers do not procure and install the required systems and software as defined in the Integrated Management Services Support Plan.
- Customers request support that is outside the purchase agreement.

The TSO does not support hardware or software that customers purchase from third-party vendors.

Avaya Network Management Software Systems Support Group (NMSSS)

The Avaya Network Management Software Systems Support Group (NMSSS) in Tampa Bay, Florida answers customer calls about products in Avaya Integrated Management. NMSSS will either answer your questions directly or connect you with an associate who can answer questions about the products.

Customized Management Solutions for Avaya Integrated Management

The Integrated Management Product Team understands customer's needs and is focused on customer satisfaction. See [Table 1: Customer-Accessible Resources](#) on page 11 for contact information. The Product Team will assist customers with Avaya Integrated Management projects and will provide:

- **Project Management** — An Integrated Management project person will work with the customer to access configuration and customization requirements for any or all applications within each Avaya Integrated Management offer. If custom work is required, the evaluation will include a proposed statement of work and price. Note that this offer is *not* intended to provide installation for customers that choose to implement Integrated Management applications using Avaya Services or third-party implementation services.
- **Training** — Basic training can be performed remotely using an interactive medium to display the applications and a conference bridge for audio. On-site training can be customized to meet the customer's needs. Customized training will focus on application functionality that is relevant to the customer and provide focused knowledge transfer to facilitate application-specific training.

Avaya Contact Information

[Table 1](#) and [Table 2](#) provide contact information that you may use if you need assistance during the process of installing and setting up Avaya Integrated Management. To access the links in [Table 2](#), you must be able to access the Avaya intranet.

Table 1: Customer-Accessible Resources

Resource	Contact Information
Avaya Support Center	http://www.avaya.com/support
Network Management Software Systems Support (NMSSS)	+1 800 237-0016
Communications, Solutions, and Integration (CSI) Group of Software Services	+1 800 730-9108, prompt 3
Integrated Management Product Team	Send email to: AIMtraining@avaya.com
Toll Fraud Intervention	+1 800 643-2353, prompt 1

Table 2: Avaya Internal Resources

Resource	Contact Information
Avaya System Management Support	http://aem-support.dr.avaya.com
Avaya Technology and Consulting (ATAC)	+1 888 297-4700, prompt 2,6 http://forum.avaya.com (requires a password)
Communications, Solutions, and Integration (CSI) Group of Software Services	http://associate2.avaya.com/sales_market/products/data-implementation-services/
Integrated Management Services Support Plan	http://associate2.avaya.com/solution/support_plans/#Enterprise

Product Documentation

The latest version of Avaya Integrated Management product documentation, including this book, is available from the Avaya Support Web Site. To view or download these books from the Web, you must have access to the Internet, an Internet browser, and Adobe Acrobat Reader, version 5.0 or later. Adobe Acrobat Reader is provided on the Enterprise Network Management CDs and is also available from <http://www.adobe.com>. See [How to Access Books on the Web](#) for instructions on how to view or download these books.

How to Access Books on the Web

To view or download books from the Avaya Support Web Site, follow these steps:

1. Access <http://www.avaya.com/support>.
2. Click **Find Documentation and Downloads by Product Name**.
3. Click the letter **I** in the alphabet listing.
4. Locate the Integrated Management product or offer name and click the corresponding link.
5. Click **View All Documents** to display a list of available books for that product or offer.

Tell Us What You Think!

Let us know how this book measured up to your expectations. Your opinions are crucial to helping us meet your needs! Send us your comments by mail, fax, or e-mail as follows:

Mail: Avaya Inc.
Avaya Integrated Management Documentation Team
Room 3C-313
307 Middletown Lincroft Rd.
Lincroft, NJ 07738
USA

Fax: Avaya Integrated Management Documentation Team
+ 1 732 852-2469

E-mail: document@avaya.com
Subject: Avaya Integrated Management Documentation Team

Chapter 2: Overview

Enterprise Network Management

Enterprise Network Management is a Windows solution for Avaya Integrated Management. It is designed for small-to-medium size networks that run Windows platforms. It provides a complete converged solution that helps you manage your network through a common web-based user interface. The VoIP SystemView provides the ability to see your whole voice system structure and hierarchy. With this offer, you can administer and manage Avaya voice systems and Avaya converged devices (such as gateways and switches).

Note:

A Solaris version of the Network Management applications included in Avaya Integrated Management is provided in the Network Management for Solaris offer.

The Enterprise Network Management offer is for one non-introductory Avaya Communication Manager and provides one user license for Avaya Communication Manager administration tools and network management and provisioning tools for Avaya solutions. Customers can purchase two additional options—one that is for up to five Avaya Communication Managers and provides up to five user licenses, and another that is for up to ten Avaya Communication Managers and provides up to ten user licenses. In addition, an add-on option is available that provides unlimited client licenses for Avaya Site Administration and Avaya Voice Announcement Manager.

Enterprise Network Management CDs

Enterprise Network Management is provided on the following CDs:

- Network Management (see [Network Management Installation](#) on page 19)
- Administration Tools (see [Administration Tools Installation](#) on page 27)
- Network Provisioning (see [Network Provisioning Installation](#) on page 33)
- VoIP Monitoring Manager (90-day trial) (see [VoIP Monitoring Manager Installation](#) on page 39)

Windows Server Requirements

[Table 3](#) provides the minimum requirements for the Windows server.

Table 3: Windows Server Requirements

Component	Required	Comments
Operating System	Microsoft Windows 2003 Standard Edition server, Microsoft Windows 2003 Enterprise Edition server, or Microsoft Windows 2000 server; VoIP Monitoring Manager can also be installed on Windows XP Professional	Only English operating systems are supported.
Processor	2.8 GHz Pentium® 4	A maximum of two processors is supported.
Hard Drive	40 GB	
Memory	1.5 GB RAM	
Network Connectivity	TCP/IP 100 Mbit Network Card	Only one network interface is supported. Dual network interface cards (NICs) or additional software network interfaces, such as a VPN interface, are not supported.
Modem	56K modem for remote access	
CD-ROM Drive		Required for installation.
Monitor	SVGA 1024 X 768 display	
SNMP Agent	The Simple Network Management Protocol (SNMP) Agent is the Windows Service that runs on your computer. It is provided with the Windows operating system CD but is not installed by default. When installing the VoIP Monitoring Manager, you will be prompted to install it, if it is not already installed.	
1 of 2		

Table 3: Windows Server Requirements (continued)

Component	Required	Comments
Extra Software	Anti-virus software pcAnywhere	Required for Avaya support. pcAnywhere is required for remote access by Avaya Services.
Web Browser	Internet Explorer 6.0	Required for access to the Integrated Management Launch Page and web-based clients.
Integration with HP OpenView Network Node Manager	HP OpenView 7.0.1 or HP OpenView 7.5	HP OpenView is not included on any Avaya Integrated Management CD. Customers must purchase, install, and maintain HP OpenView. While Avaya services support Integrated Management when installed over HP OpenView, they do not support the HP OpenView product itself.
Port (for Avaya VoIP Monitoring Manager)	The Avaya VoIP Monitoring Manager client and server software communicate using Java Remote Method Invocation (RMI), and use port 1099 on the machine on which the server is running. If this port is unavailable, the server will attempt to use the following ports: 49177, 51173, or 63006. Although it is unlikely that all of these ports will be in use on a single machine, ensure that at least one of these ports is available.	
2 of 2		

Windows Client PC Requirements

[Table 4](#) provides the requirements for the Windows client PC.

Table 4: Windows Client PC Requirements

Component	Required	Comments
Operating system	Microsoft Windows 2000, Windows XP Professional, or Windows 2003	
Processor	600 MHz Pentium®	
Hard Drive	1 GB	Required to install all of the client components.
Memory	256 MB RAM	
Monitor	SVGA 1024 X 768 display	
Network Connectivity	TCP/IP 10/100 Network Card	
Modem	56K Modem	May be required for remote access to the client PC.
CD-ROM Drive		Required for installation.
Web Browser	Internet Explorer 6.0	Required to access the Integrated Management Launch Page and web-based clients.

Pre-Installation Tasks

Before installing Avaya Integrated Management products, you must complete the following pre-installation tasks.

1. Check the minimum hardware and software requirements for the following:
 - Windows server (see [Windows Server Requirements](#) on page 14).
 - Windows client PC (see [Windows Client PC Requirements](#) on page 16).
2. For upgrade installations, check that all previous sequential upgrades and/or major releases of Avaya Integrated Management products were installed before installing this release. If the wizard detects a software upgrade that is not sequential, the wizard will stop and display a message to install the skipped releases. The wizard will then abort the installation.
3. Carefully review *Avaya Integrated Management Implementation Guidelines*, document number 555-233-163. This document is available from the Avaya Support Web Site. (See [How to Access Books on the Web](#) on page 12.) This document describes server configuration requirements and provides pre-installation forms that must be completed before you begin installing the Avaya Integrated Management products. The pre-installation forms contain information that you will need to install the products, such as IP addresses, server domain names, and port addresses.
4. If you plan to run HP OpenView, you must install HP OpenView on the Windows server **before** you install the Network Management applications. When HP OpenView is present, the Network Management Console with System View is unavailable, and HP OpenView acts as the launch point for the applications and device managers.

Note:

Provisioning and Installation Manager cannot be used with HP OpenView integration.

5. If you have a large system (greater than 1000 simultaneous IP calls) or plan to keep historic VoIP Monitoring Manager data for long periods of time, it is recommended that you install VoIP Monitoring Manager on a separate server than that on which Network Management Console with System View is installed.

If you plan to install VoIP Monitoring Manager, but you do not plan on using the Network Management Console with System View, do not install Network Management Console with System View on the same server. VoIP Monitoring Manager performance is improved when fewer applications are using server resources.

6. To install the Network Management applications, you will need the IP addresses of the servers on which the following optional applications reside:
 - Avaya Fault and Performance Manager
 - Avaya Proxy Agent
 - MultiSite Administration
 - Integrated Management Database
 - VoIP Monitoring Manager (if not installed on this server)
 - SIP Enablement Services
 - Motorola NMS
 - Integral easy Management
 - Message Networking
 - Modular Messaging
 - Voice Mail System Configuration
 - Polycom GMS
 - Extreme EPICenter
7. Carefully review this entire book before you start the installations on the servers and client PCs.

Integrated Management Server

In Avaya Integrated Management Release 3.1, the server contains the IP addresses of all the products on the various servers. The server containing this information is called the Integrated Management server. You have the option of designating either the Linux server or the Windows server as the Integrated Management server.

During the installation, the wizard prompts you for the IP address of the Integrated Management server. This prompt appears during the installation of Windows server products, Windows client products, and Linux server products (in the System Management offer). You must enter the same IP address each time you are prompted for the IP address of the Integrated Management server. Without the correct IP address, users will be unable to access the Integrated Management Launch Page where they can launch products from their browsers.

Chapter 3: Network Management Installation

Network Management CD

The Network Management CD contains products that you install onto the Windows server. See [Windows Server Requirements](#) on page 14 for the minimum server requirements. Before installing this CD, see [Pre-Installation Tasks](#) on page 17.

The Network Management CD contains the following applications:

- Network Management applications:
 - Avaya Network Management Console with System View
 - Avaya Network Configuration Manager
 - Avaya Software Update Manager
 - Avaya SMON Manager (90-day trial) – Customers can purchase the license key to activate the SMON Manager beyond the 90-day trial.
 - Avaya Address Manager
 - Avaya QoS Manager
 - Avaya Secure Access Administration
- Avaya Device Managers:
 - Avaya G350/250 Manager
 - Avaya P330/G700 Manager
 - Avaya C360 Manager
 - Avaya W310 Manager
 - Avaya C460 Manager
 - Avaya P130 Manager
- Additional components:
 - OpenSSH SCP Server (installed so that Avaya Software Update Manager can use this SCP server for secure file transfer)
 - Avaya Integrated Management Launch Page (automatically installed when any application is installed)
 - Apache Web server
 - Adobe Acrobat Reader (required to view documents)

Avaya SMON Manager License Key

The Enterprise Network Management offer provides a 90-day trial version of Avaya SMON Manager. Customers have the option of purchasing the SMON Manager license key. This key is required to fully activate the SMON Manager beyond the 90-day trial period. The license key is available as an add-on option.

HP OpenView Integration

The Network Management applications provided in the Enterprise Network Management offer can integrate with HP OpenView on the Windows server. HP OpenView must be installed on the server *before* the Network Management applications are installed. HP OpenView 7.0.1 or 7.5 is required.

HP OpenView IP Telephony Smart Plug In (IPT-SPI) is available. It is supported only with HP OpenView Network Node Manager (NNM) 7.5. If you are installing IPT-SPI, be sure HP OpenView NNM 7.5 is installed first, and then install IPT-SPI. This order of installation will ensure the correct icons are installed.

Note:

HP OpenView and IPT-SPI are not provided on the Network Management CD. Avaya Services does not support HP OpenView, IPT-SPI, or other third party products.

Installing the Software

Use this procedure to install the Network Management applications and Device Managers on the Windows server. The procedure to install or to upgrade Network Management applications and Device Managers on the Windows server is generally the same.

This procedure also provides steps to help you configure your VoIP Media Servers and gather information required to properly discover and manage your voice network with this network management station.

1. Ask all users to log off the system.
2. Close all open windows and applications.
3. Insert the **Avaya Integrated Management, Network Management 3.1** CD into the CD-ROM drive.

The Avaya Integrated Management, Network Management window appears. It provides the main menu.

Note:

Install Acrobat Reader if it is not already installed on the computer.

4. Click **Install Network Management**.

The Welcome dialog box appears.

5. Click the **Next** button.

The License Agreement dialog box appears.

6. Read the license agreement. If you accept the license agreement, click the **I accept the terms of the license agreement** option button, and then click the **Next** button.**Note:**

You must accept the terms of the license agreement in order to continue with the installation.

The Choose Destination Location dialog box appears. By default, the files will be installed in **c:\Program Files\Avaya**.

7. Perform one of the following steps:

- To install the files in the default folder, click the **Next** button.
- To change the folder where the files will be installed, click the **Change** button, specify the folder you want to use, and then click the **Next** button.

The Select Features dialog box appears. This dialog box displays the applications and components you can install.

Note:

Avaya Secure Access Administration and Avaya Address Manager cannot be deselected. The wizard automatically installs these components.

8. Make sure the applications you want to install are selected. Perform the following steps:

a. Click **Device Managers** and then click the **Change** button.

The Select Subfeatures dialog box appears. By default, all Device Managers are selected.

b. If you do not want to install all of the Device Managers, click the check box for each device manager you do not want to install to deselect it, and then click the **Continue** button.9. Click the **Next** button.

One of the following appears:

- If IIS (Microsoft's Web Server) is detected on the server, the IIS Installation Detected dialog box appears. Enter the new port number on which IIS should run, and then click the **Next** button. By default, the new port is 8989.

The Apache Server Information dialog box appears. Go to Step [10](#).

- If IIS is not detected on the server, the Apache Server Information dialog box appears. Go to Step [10](#).

10. Enter the Network Domain, Server Name, and Administrator's E-mail Address. By default, Apache HTTP server programs and short cuts will be installed for all users. You can specify to install Apache HTTP server programs and short cuts for the current user only.

Note:

The Network Domain, Server Name, and Administrator's E-mail fields must be completed. The Administrator's e-mail address allows the system to notify the administrator if problems occur during the Apache installation.

11. Click the **Next** button.

The Enter IP Addresses dialog box appears.

12. Enter the IP address of the Avaya Integrated Management Launch Page server, Avaya Fault and Performance Manager server, and the Avaya Proxy Agent server, and then click the **Next** button.

The Enter IP Addresses dialog box appears.

Note:

You are not required to enter the IP address of the Avaya Integrated Management Launch Page Server. However, if you leave this blank and click the **Next** button, no link to the Launch Page will be provided on the server.

13. Enter the IP address of the MultiSite Administration server, the Integrated Management Database server, and the VoIP Monitoring Manager server, and then click the **Next** button.

The Enter IP Addresses dialog box appears.

14. Enter the IP address of the SIP Enablement Services server, Motorola NMS server, and Integral easy Management server, and then click the **Next** button.

The Enter IP Addresses dialog box appears.

15. Enter the IP Address of the Message Networking server, Modular Messaging server, and Polycom GMS server, and then click the **Next** button.

The Enter IP Address dialog box appears.

16. Enter the IP Address of the Voice Mail System Configuration server, and then click the **Next** button.

The Enter IP Address and Port dialog box appears.

17. Enter the IP address and port number of the Extreme EPICenter server, and then click the **Next** button.

Note:

Leave these fields blank if you do not have an Extreme EpiCenter server.

The User Name and Passwords dialog box appears.

18. Enter the user name and password for logging in to the Network Management applications and for accessing SNMPv3, and then click the **Next** button.

The User Name and Passwords dialog box appears.

19. Enter the SNMPv3 privacy password, enter it again to confirm, and then click the **Next** button.

The SCP User Management dialog box appears.

20. From the left side of the SCP User Management dialog box, select the appropriate users you want to add to the SCP Server, and click the right arrow button.

21. Click the **Next** button.

The Start Copying Files dialog box appears.

22. Review the setup summary, and then click the **Next** button.

The installation status bar appears while files are configured and installed.

When the installation is complete, the welcome dialog box for the Avaya Enterprise Network Management Configuration Wizard appears. This wizard will help you configure your VoIP media servers and gather information required to properly discover and manage your voice network with this network management station.

23. Click the **Next** button.

The Configure CM Servers dialog box appears.

24. In the Configure CM Servers dialog box, perform the following steps:

- a. Click the **New** button to add the Avaya Communication Manager servers you want to manage.
- b. Enter the IP Address and login for the Avaya Communication Manager server.
- c. Do one of the following:
 - Click the **Password** option button, and then enter the password.
 - Click the **ASG key** option button, and then enter the ASG key.
- d. Select the appropriate protocol from the menu.
- e. Click the **Next** button.
- f. Validate the server certificate, and then click the **Yes** button.

The new Avaya Communication Manager server appears in the Configure CM Servers dialog box.

- g. Repeat Steps a through f for each Avaya Communication Manager server you want to add. When finished adding Avaya Communication Manager servers, click the **Next** button.

The Configure Global SNMP Parameters dialog box appears.

25. In the Configure Global SNMP Parameters dialog box, perform the following steps:

- a. Click the **New** button to add one or more sets of SNMP Parameters.
- b. Perform one of the following steps:
 - If the SNMP parameters are for an existing user, click the **Existing SNMPv3 User** option button, and then select the user from the **Select User** menu.
 - If the SNMP parameters are for a new user, click the **New SNMPv3 User** option button, and then perform the following steps:
 1. Enter the User Name.
 2. Enter the Authentication Password, and then enter it again to verify.
 3. Select the Authentication Scheme from the menu.
 4. Enter the Privacy Password, and then enter it again to verify.
 - If you want to configure SNMPv1 Community, click the **SNMPv1 Community** option button, and then do the following:
 1. Enter the Read Community string.
 2. Enter the Read/Write Community string.
- c. Click the **Next** button.

The new SNMP parameters appear in the Configure Global SNMP Parameters dialog box.

- d. Click the **Next** button.

The Configure Network Subnet to Discover dialog box appears.

26. In the Configure Network Subnet to Discover dialog box, perform the following steps:

- a. Click the **New** button to add the IP network you want to discover.
- b. Enter the Subnet IP Address.
- c. Perform one of the following steps:
 - Click the **Subnet Mask** option button, and then enter the subnet mask.
 - Click the **Router** option button, and then enter the router for this subnet.
- d. Click the **Next** button.

The new IP network appears in the Configure Network Subnet to Discover dialog box.

- e. Repeat Steps a through d for each IP network you want to discover. When finished adding IP networks, click the **Next** button.

The Configuration Complete dialog box appears.

27. Click the **Finish** button.

The InstallShield Wizard Complete dialog box appears.

28. Remove the CD from the CD-ROM drive.
29. Click the **Yes, I want to restart my computer now** option button, and then click the **Finish** button. The computer will reboot and the network discovery will automatically begin when the computer restarts.

If you performed the Network Management Configuration tasks during the installation, you can access the products by selecting **Start > Programs > Avaya > Network Management**. For more information about an Avaya Integrated Management product, access the online help after you start the application.

If you did not perform the Network Management configuration tasks using the Avaya Enterprise Network Management Configuration Wizard during the installation, or if you want to change the Network Management configuration parameters, see *Avaya Integrated Management Release 3.1, Enterprise Network Management Configuration*, document number 14-300210.

Note:

Regularly check the Avaya Support Web Site for software updates.

Uninstalling the Software

Use this procedure to uninstall the Network Management applications and Device Managers from the Windows server.

1. Select **Start > Control Panel**.
The Control Panel window appears.
2. Click on **Add or Remove Programs**.
The Add or Remove Programs window appears.
3. Click on **Avaya Integrated Management Network Management 3.1**.
4. Click the **Remove** button.
A dialog box appears prompting you to confirm that you want to remove the applications.
5. Click the **Yes** button.
The status bar appears while files are uninstalled. Then you are prompted to uninstall Apache.
6. Click the **Yes** button.
The status bar appears while Apache is uninstalled. Then you are prompted to set IIS back to port 80.
7. Click the **Yes** button.
The Uninstall Complete dialog box appears.
8. Click the **Yes, I want to restart my computer now** option button, and then click the **Finish** button.

Changing an Application Link on the Avaya Integrated Management Launch Page

A server configuration tool is available that allows you to change an application link on the Avaya Integrated Management Launch Page after an application has been installed. To do this, follow these steps:

1. Select **Start > Programs > Avaya > Configure Integrated Management**.

The Configure Utility dialog box appears.

2. To change the link of an Integrated Management application, click the **Avaya Integrated Management Information** tab and change the IP address of the application.
3. If you want the application links for Avaya Site Administration and Voice Announcement Manager to appear on the Avaya Integrated Management Launch Page, check the checkboxes for those applications.
4. Click the **Save** button.
5. To change the link of an adjunct application, click the **Adjunct Management Information** tab and change the IP address of the application.
6. If you want the application link for Mailbox Manager to appear on the Avaya Integrated Management Launch Page, check the checkbox for that application.
7. Click the **Save** button.
8. Click the **Exit** button when finished.

Chapter 4: Administration Tools Installation

Administration Tools CD

The Administration Tools CD contains products that you install directly onto the Windows client PCs. See [Windows Client PC Requirements](#) on page 16 for the minimum PC requirements. Before installing this CD, also see [Pre-Installation Tasks](#) on page 17.

The Administration Tools CD contains the following applications:

- **Avaya Site Administration**

Avaya Site Administration enables you to

- administer and manage voice systems running Avaya Communication Manager software
- add, change, and remove mailboxes on messaging systems

To simplify your day-to-day administration tasks (such as finding unused stations, changing users, and adding users), Avaya Site Administration provides several wizards. At any time, you can use the GEDI in Avaya Site Administration to enter Avaya Communication Manager commands that you would typically enter from a terminal emulation window or system administration terminal (SAT).

- **Avaya Voice Announcement Manager**

Avaya Voice Announcement Manager enables you to administer and manage audio files and announcement properties on voice systems running Avaya Communication Manager software. Using Avaya Voice Announcement Manager, you can

- add, change, and remove Avaya Communication Manager announcement information
- copy audio files and announcement properties from a PC to voice systems and back
- back up and restore announcement information
- view the status of announcements on VAL boards and virtual VAL boards
- move announcement files between VAL boards and virtual VAL boards
- broadcast announcement files to VAL boards and virtual VAL boards on different voice systems
- import and export announcement properties

- **OpenSSH SCP Server**

In Integrated Management Release 3.1, Avaya Voice Announcement Manager enables you to use an SCP server for secure file transfer to G250 and G350 media gateways. These media gateways have an SCP client. You can either use an existing SCP server or install OpenSSH SCP Server from the Administration Tools CD.

When you install OpenSSH SCP Server from the Administration Tools CD, the SCP server is installed on the same PC as the Administration Tools applications. During OpenSSH SCP Server installation, you are able to select Windows users on that PC and configure them as users for the SCP server. When SCP users log on to the PC, they are automatically logged on to the SCP server as well.

- **Adobe Acrobat Reader**

Adobe Acrobat Reader is required to view documents that are provided on the CD.

Installing the Administration Tools

This section describes how to install Avaya Site Administration and Avaya Voice Announcement Manager. The procedure to install or upgrade these applications is generally the same.

1. Close all open windows and applications.
2. Insert the **Avaya Integrated Management, Administration Tools 3.1 CD** into the CD-ROM drive.

The Avaya Integrated Management Administration Tools 3.1 window appears. It provides a main menu.

Note:

Install Acrobat Reader if it is not already installed on the computer.

3. Click **Install Administration Tools**.

The Welcome dialog box appears.

4. Click the **Next** button.

The License Agreement dialog box appears.

5. Read the license types. If you accept the license types, click the **I accept the terms of the license agreement** option button, and then click the **Next** button.

Note:

You cannot install the Avaya Integrated Management products unless you accept the license types.

The Choose Destination Location dialog box appears. By default, the applications will be installed in **c:\Program Files\Avaya**.

6. Perform one of the following steps:

- To install the applications in the default folder, click the **Next** button.
- To change the folder where the applications will be installed, click the **Change** button, specify the folder you want to use, and then click the **Next** button.

The Select Features dialog box appears. This dialog box displays the applications and components you can install.

7. Make sure the applications you want to install are selected, and then click the **Next** button.

The Avaya Integrated Management Launch Page Server dialog box appears.

8. Enter the IP address of the Avaya Integrated Management Launch Page Server, and then click the **Next** button.

Note:

You are not required to enter the IP address of the Avaya Integrated Management Launch Page Server. However, if you leave this blank and click the **Next** button, no link to the Launch Page will be provided on the PC.

The Start Copying Files dialog box appears.

9. Click the **Next** button.

The Setup Status message box appears showing the status of the installation. When the installation is complete, the InstallShield Wizard Complete dialog box appears.

10. Click the **Finish** button to exit the installation wizard.

11. Perform one of the following steps:

- If you want to install the OpenSSH SCP server, see [Installing OpenSSH SCP Server](#) on page 30.
- If you do not want to install the OpenSSH SCP server, go to Step [12](#).

12. Remove the CD from the CD-ROM drive, and then click **Exit** from the main menu.

You can access the products by double-clicking the desktop icon or selecting **Start > All Programs > Avaya**. For more information about an Avaya Integrated Management product, access the online help after you start the application.

Note:

Regularly check the Avaya Support Web Site for software updates.

Installing OpenSSH SCP Server

This section describes how to install OpenSSH SCP Server and configure any Windows user on the PC as a user for the SCP server. See [OpenSSH SCP Server](#) on page 28 for more information. You do not need to install OpenSSH SCP Server if you already have an SCP server installed and administered.

1. From the Avaya Integrated Management Administration Tools 3.1 main menu, click **Install OpenSSH SCP Server**.

The Welcome dialog box appears.

Note:

If the Avaya Integrated Management Administration Tools 3.1 main menu is not already open, see Steps 1 and 2 under [Installing the Administration Tools](#) on page 28.

2. Click the **Next** button.

The SCP User Management dialog box appears.

3. From the left side of the SCP User Management dialog box, select the appropriate users you want to add to the SCP Server, and click the right arrow button.

4. Click the **Next** button.

The Ready to Install the Program dialog box appears.

5. Click the **Install** button.

The Setup Status message box appears showing the status of the installation. When the installation is complete, the InstallShield Wizard Complete dialog box appears.

6. Remove the CD from the CD-ROM drive.

7. Click the **Yes, I want to restart my computer now** option button, and then click the **Finish** button.

You can manage the user list by using the SCP User Management Tool. Select **Start > Programs > Avaya > SCP User Configuration**.

Note:

You must configure the SCP server from Avaya Voice Announcement Manager. See the online help for Avaya Voice Announcement Manager for more information.

Starting Avaya Site Administration

To start Avaya Site Administration, perform one of the following steps:

- Double-click the Avaya Site Administration shortcut on the desktop.
- Select **Start > All Programs > Avaya > Site Administration**.

The Avaya Site Administration window appears. See the online help for information on how to use Avaya Site Administration.

Starting Voice Announcement Manager

To start Avaya Voice Announcement Manager, perform one of the following steps:

- Double-click the Avaya Voice Announcement Manager shortcut on the desktop.
- Select **Start > All Programs > Avaya > Voice Announcement Manager**.

The Avaya Voice Announcement Manager window appears. See the online help for information on how to use Avaya Voice Announcement Manager.

Uninstalling the Administration Tools

This section describes how to uninstall Avaya Site Administration and Avaya Voice Announcement Manager.

1. Select **Start > Control Panel**.

The Control Panel window appears.

2. Double-click on **Add or Remove Programs**.

The Add or Remove Programs window appears.

3. Click on **Avaya Integrated Management Administration Tools 3.1**.

4. Click the **Remove** button.

A dialog box appears prompting you to confirm that you want to remove the applications.

5. Click the **Yes** button.

The Uninstall Complete dialog box appears.

6. Click the **Finish** button.

7. Close the Add or Remove Programs window.
8. Close the Control Panel Window.

Uninstalling OpenSSH SCP Server

This section describes how to uninstall OpenSSH SCP Server.

1. Select **Start > All Programs > OpenSSH for Windows > Remove OpenSSH for Windows**.

The Uninstall Wizard appears.

2. Click the **Next** button.

The Uninstall OpenSSH for Windows dialog box appears.

3. Click the **Uninstall** button.

The Completing the OpenSSH for Windows Uninstall Wizard dialog box appears.

4. Click the **Finish** button to exit the wizard.

Chapter 5: Network Provisioning Installation

Overview of Provisioning and Installation Manager

Provisioning and Installation Manager provides the capability to remotely configure Avaya media gateways on a network-wide basis. It provides integrated network system views that ease centralized configuration tasks, especially provisioning and installing large numbers of gateways simultaneously.

Provisioning and Installation Manager enables you to:

- Create templates and device profiles to use later.
- Import and export device profiles and templates.
- Save templates and device profiles as an incomplete status or completed.
- Copy configuration templates and device profiles to create placeholders for different parameters.
- Create a template from scratch or import data from an electronic pre-installation worksheet (EPW).
- Distribute a template through bulk provisioning to a group of devices.
- Send a profile to a device and make a choice to distribute now, schedule for a later, or make pending.
- Configure G250 media gateways with Standard Local Survivability (SLS) updates that include parameters such as automatic route selection (ARS) rules and dial plans.
- Store notes about templates and device profiles.

Provisioning and Installation Manager supports the following media gateways:

- Avaya G250
- Avaya G250-BRI
- Avaya G250-DS1
- Avaya G250-DCP
- Avaya G350

Pre-Installation Tasks

Before installing Provisioning and Installation Manager, you must complete the following pre-installation tasks.

1. Check the minimum hardware and software requirements for the following:
 - Windows server (see [Windows Server Requirements](#) on page 14).
 - Windows client PC (see [Windows Client PC Requirements](#) on page 16).
2. Because Provisioning and Installation Manager uses the same version of Apache and JRE as those installed by the Network Management CD, the following prerequisites must be met:
 - Provisioning and Installation Manager must be installed on the same Windows server as the Network Management applications. The releases must be the same, and the build must be compatible.
 - The following Integrated Management applications included on the Network Management CD must be installed on the Windows server before Provisioning and Installation Manager is installed:
 - Avaya Network Management Console with System View
 - Avaya Secure Access Administration

Note:

Avaya Network Management Console with System View is available only if HP OpenView Network Node Manager (NNM) is not present. Provisioning and Installation Manager cannot be used with HP OpenView integration.

3. Carefully review *Avaya Integrated Management Implementation Guidelines*, document number 555-233-163. This document is available from the Avaya Support Web Site. (See [How to Access Books on the Web](#) on page 12.) This document describes server configuration requirements and provides pre-installation forms that must be completed before you begin installing the Avaya Integrated Management products. The pre-installation forms contain information that you will need to install the products, such as IP addresses, server domain names, and port addresses.
4. Carefully review this entire book before you start the installation.

Note:

If you are installing Provisioning and Installation Manager on a Windows 2003 server, ensure that the browser security settings are set to allow active scripting. See [Ensuring Browser Settings Allow Active Scripting](#) on page 35.

Ensuring Browser Settings Allow Active Scripting

If you are installing Provisioning and Installation Manager on a Windows 2003 server, be sure the server's browser security settings are set to allow active scripting. Active scripting must be enabled in order for all components in the Provisioning and Installation Manager graphical user interface (GUI) to appear when you launch the application.

To ensure browser settings are set to allow active scripting, follow these steps:

1. From the toolbar In your browser window, select **Tools > Internet Options**.
2. Click the **Security** tab, and then click the **Custom Level** button.
3. Scroll down to **Scripting**, and ensure **Active Scripting** is enabled.

Network Provisioning CD

The Network Provisioning CD contains the following applications:

- Provisioning and Installation Manager
- Adobe Acrobat Reader (required to view documents)

Note:

Provisioning and Installation Manager is intended for large branch office deployments. The Network Provisioning CD is not automatically shipped with the Enterprise Network Management offer. To receive this CD, contact your sales representative.

Installing the Software

To install Provisioning and Installation Manager, follow these steps:

1. Ask all users to log off the system.
2. Close all open windows and applications on the Windows server.
3. Verify that the following Integrated Management applications are installed on the Windows server:
 - Avaya Network Management Console with System View
 - Avaya Secure Access Administration

4. Insert the **Avaya Integrated Management 3.1, Network Provisioning CD** into the CD-ROM drive.

The Avaya Provisioning and Installation Manager 3.1 window appears. It provides the main menu.

Note:

Install Acrobat Reader if it is not already installed on the computer.

5. Click **Install PIM 3.1**.

The Welcome dialog box appears.

6. Click the **Next** button.

The License dialog box appears.

7. Read the license agreement. To accept the license agreement, select **I accept the terms of the license agreement**, and then click the **Next** button.

The Tomcat Configuration dialog box appears.

8. Enter the Web access port for Tomcat, and click the **Next** button. The default port is 2020.

The Setup Summary dialog box appears.

9. Review the setup summary, and then click the **Next** button.

The installation status bar appears. When the installation is complete, the InstallShield Wizard Complete dialog box appears.

10. Remove the CD from the CD-ROM drive, and then click the **Finish** button to restart the server.

See *Avaya Integrated Management Release 3.1, Provisioning and Installation Manager Configuration*, document number 14-300286, for tasks that must be performed before you use Provisioning and Installation Manager for the first time. For more information about Provisioning and Installation Manager, access the online help after you start the application.

Note:

Regularly check the Avaya Support Web Site for software updates.

Uninstalling the Software

Use this procedure to uninstall Provisioning and Installation Manager from the Windows server.

1. Select **Start > Control Panel**.

The Control Panel window appears.

2. Click on **Add or Remove Programs**.

The Add or Remove Programs window appears.

3. Click on **Avaya Provisioning and Installation Manager 3.1**.

4. Click the **Remove** button.

The Repair or Remove the Program dialog box appears.

5. Click the **Remove** option button, and then click the **Next** button.

A dialog box appears prompting you to confirm that you want to remove the application.

6. Click the **Yes** button.

The Maintenance Complete dialog box appears.

7. Click the **Yes, I want to restart my computer now** option button, and then click the **Finish** button.

Chapter 6: VoIP Monitoring Manager Installation

What is Avaya VoIP Monitoring Manager?

Avaya Voice Over IP (VoIP) Monitoring Manager is a VoIP Quality of Service (QoS) monitoring tool. It enables you to monitor and review the quality of a call on an Avaya VoIP Network.

Avaya VoIP Monitoring Manager allows you to view QoS data (such as jitter, round trip time (RTT), and packet loss) experienced at the endpoints and during a session. This data displays in real-time or for previously active endpoints. With this information, you can begin to troubleshoot and isolate problems.

Avaya VoIP Monitoring Manager allows you to:

- **Search Endpoints.** You can search endpoints active from a specified time in the past or between a date range. Advanced search options enable you to narrow your search to match phone numbers, network addresses, or QoS levels.
- **View Reports.** Once you have a list of endpoints, you can select one or more endpoints in a session and view the associated reports. The reports display QoS data such as jitter, round trip time (RTT), and packet loss. This is particularly useful for monitoring gateways or locating problems at a particular endpoint.

Since you can view reports for endpoints involved in a session, this information will assist you with determining problems that occur between two endpoints or in an isolated area of the network.

- **Export Reports.** You can export the report data to a comma separated value (csv) file. You can open this file in most database and spreadsheet programs such as Microsoft Excel. Exporting the data to a spreadsheet enables you to manipulate the data so you can create your own reports.
- **Generate Automatic Alarms.** You can generate Simple Network Management Protocol (SNMP) traps/alarms, which allow the VoIP Monitoring Manager to alert you when the jitter, RTT, or packet loss reaches certain levels. You can routinely monitor the network and troubleshoot problems.

Avaya VoIP Monitoring Manager Components

The Avaya VoIP Monitoring Manager incorporates the Avaya VoIP Monitoring Manager Real-time Transport Control Protocol (RTCP) Monitor and the Avaya VoIP Monitoring Manager Server, which accepts connections from the Avaya VoIP Monitoring Manager Client. The server software must be installed on the network to work correctly. A Windows SNMP Agent must also be installed on the server.

VoIP Monitoring Manager also uses a database. During installation, the VoIP Monitoring Manager Integrated MSDE Database is installed by default. However, you can choose to install a different Microsoft SQL database.

The components and their relationship are described in more detail in the following sections.

Avaya VoIP Monitoring Manager Server

The Avaya VoIP Monitoring Manager Server acts as a proxy between the MSDE database and the Avaya VoIP Monitoring Manager Client. It manages connectivity to the database and provides an interface to configure the Avaya VoIP Monitoring Manager RTCP Monitor. The Avaya VoIP Monitoring Manager Server is a Java application that runs as a Windows service on the same PC as the RTCP Monitor. The database can reside on the same PC as the server and RTCP Monitor, or it can reside on a separate PC.

Avaya VoIP Monitoring Manager RTCP Monitor

The Avaya VoIP Monitoring Manager RTCP Monitor collects the RTCP packets sent from the Avaya endpoints and stores the information in a proprietary database. The RTCP Monitor also runs as a sub-agent of the Windows SNMP Agent. All the information contained in the database can be queried using Microsoft SQL.

Avaya VoIP Monitoring Manager Client

The Avaya VoIP Monitoring Manager Client provides the graphical user interface (GUI) to view the VoIP Monitoring Manager data. The client does not communicate with the RTCP Monitor, does not use the Windows SNMP service, and does not communicate with the database. The data that is displayed is gathered from the Avaya VoIP Monitoring Manager Server. The Avaya VoIP Monitoring Manager Client may be installed on the same PC as the Avaya VoIP Monitoring Manager Server, or it may be installed on another PC on the network.

Avaya VoIP Monitoring Manager Web Client

The Avaya VoIP Monitoring Manager Client can run as a Web application in a browser. This is useful if you only have the Avaya VoIP Monitoring Manager Server installed. To run the Avaya VoIP Monitoring Manager Client as a Web application, the following requirements must be met:

- The PC on which Avaya VoIP Monitoring Manager Server is installed must be running a Web server. The Apache Web server is automatically installed on the server when the Avaya VoIP Monitoring Manager Server software is installed.
- The Web server must be configured to publish the file to the following VoIP Monitoring Manager installation path:

C:\Program Files\Avaya\VoIP Monitoring Manager\jars\ClientApplet.htm

Note:

The server installation will apply this configuration.

- The PC you will use to access the Avaya VoIP Monitoring Manager Server must be able to connect to the VoIP Monitoring Manager Server via a web browser and have the following software installed:
 - Microsoft Internet Explorer 6.0 or later
 - SUN Java 2 Runtime Environment, SE v1.4.2_06

If you run the Web client, you will not have access to some of the features—such as connecting to a new server and copying—that are available in the application.

WebLM License Server

The WebLM License Server manages your licenses for Avaya Integrated Management products. It is required when you purchase the VoIP Monitoring Manager license key to activate VoIP Monitoring Manager beyond the 90-trial period. The WebLM License Server is not required to use the 90-day trial version.

The WebLM License Server application is provided on the VoIP Monitoring Manager CD. If you have purchased the VoIP Monitoring Manager license key, install the WebLM License Server. If the WebLM License Server is already installed on another server, you do not have to install it. During the installation, you will be prompted for the IP address of the server where the WebLM application is installed.

See [Avaya VoIP Monitoring Manager License Key](#) on page 44 for more information about VoIP Monitoring Manager licenses. See [Installing VoIP Monitoring Manager Licenses](#) on page 55 for instructions on how to install VoIP Monitoring Manager licenses.

Pre-Installation Tasks

Before installing Avaya VoIP Monitoring Manager, you must complete the following pre-installation tasks.

1. Check the minimum hardware and software requirements for the server. (See [VoIP Monitoring Manager System Requirements](#) on page 45.)

Note:

The client and server software communicate using Java Remote Method Invocation (RMI), and use port 1099 on the machine on which the server is running. If this port is unavailable, the server will attempt to use the following ports: 49177, 51173, or 63006. Although it is unlikely that all of these ports will be in use on a single machine, ensure that at least one of these ports is available.

2. If you are upgrading from the previous release, check that all previous sequential upgrades and/or major releases of Avaya VoIP Monitoring Manager were installed before installing this release. If the wizard detects a software upgrade that is not sequential, the wizard will stop and display a message to install the skipped releases.

Note:

If you are upgrading Avaya VoIP Monitoring Manager and there are previous releases of other Integrated Management applications on the Windows server, you must either upgrade the other Integrated Management applications to this version of Avaya VoIP Monitoring Manager, or install the new version of Avaya VoIP Monitoring Manager on another Windows server.

3. If you have a large system (greater than 1000 simultaneous IP calls) or plan to keep historic VoIP Monitoring Manager data for long periods of time, it is recommended that you install VoIP Monitoring Manager on a separate server than that on which Network Management Console with System View is installed.
4. Ensure that the Windows Simple Network Management Protocol (SNMP) Agent is installed on the Windows server and set to start automatically. (See [Ensuring Windows SNMP Service is Installed](#) on page 43.)
5. Carefully review *Avaya Integrated Management Implementation Guidelines*, document number 555-233-163. This document is available from the Avaya Support Web Site. (See [How to Access Books on the Web](#) on page 12.) This document describes server configuration requirements and provides pre-installation forms that must be completed before you begin installing the Avaya Integrated Management products. The pre-installation forms contain information that you will need to install the products, such as IP addresses, server domain names, and port addresses.

6. Complete the Ready Reckoner form. This form is available in the *Avaya Integrated Management Implementation Guidelines*, document number 555-233-163. Completing this form will help you predict the size of your database and therefore help you determine if the MSDE database will meet your needs. If not, a larger database such as Microsoft SQL 2000 can be installed. You can also use the Ready Reckoner form to adjust numbers, such as RTCP Reporting Intervals and History Days to determine how to set them to achieve the desired goal. Changing some numbers can help you obtain better data.
7. Carefully review this entire book before you start the installation.

Ensuring Windows SNMP Service is Installed

The Windows SNMP Service must be installed on the PC on which you are going to install the Avaya VoIP Monitoring Manager Server. The Windows SNMP Service enables the RTCP Monitor to publish the data and is required for the VoIP Monitoring Manager Server software to function.

The Windows SNMP Service is provided on the Microsoft Windows operating system CD. It is not automatically installed when the Windows operating system is installed. Before installing the VoIP Monitoring Manager software, you must confirm that the Windows SNMP Service is installed on the VoIP Monitoring Manager server and set to start automatically. To do this, follow these steps:

1. Click **Start > Settings > Control Panel**.
2. Select **Administrative Tools**.
3. Select **Services** from the list in the **Name** column.
4. Scroll down to see if **SNMP Service** is installed. It should appear in the **Name** column and be set to start automatically.
5. If SNMP Service is not set to run automatically or does not appear, do one of the following:
 - If the SNMP service is installed but not set to run automatically, do the following:
 1. Right-click on **SNMP** and select **Properties** from the context menu.
The SNMP Service Properties dialog box opens.
 2. Select **Automatic** from the **Startup Type** drop down list and click **OK**.
 - If the Windows SNMP Service is not installed, you must install it from the Windows operating system CD.

Note:

When you install the SNMP Service from the Windows operating system CD, you must configure a community name with read-write community rights. See [Checking for a Valid Community Name](#) on page 56.

VoIP Monitoring Manager CD

The VoIP Monitoring Manager CD contains the following components:

- VoIP Monitoring Manager Client (90-day trial version)
- VoIP Monitoring Manager Server (90-day trial version)
- WebLM License Server (optional component required to fully activate VoIP Monitoring Manager beyond the 90-day trial period; not required for the 90-day trial version)
- Adobe Acrobat Reader (required to view documents)

Note:

The VoIP Monitoring Manager Server software must be installed on a machine connected to the network. The VoIP Monitoring Manager Client software may be installed on the same machine as the server, or it may be installed on another machine on the network.

Avaya VoIP Monitoring Manager License Key

The VoIP Monitoring Management offer provides a 90-day trial version of VoIP Monitoring Manager. Customers have the option of purchasing the VoIP Monitoring Manager license key. This key is required to fully activate the VoIP Monitoring Manager beyond the 90-day trial period. The license key is available as an add-on option in the Avaya Integrated Management offers. When a license key is purchased, an instance of WebLM License Server is required to manage the license key. See [WebLM License Server](#) on page 41 for more information about the WebLM License Server. See [Installing VoIP Monitoring Manager Licenses](#) on page 55 for instructions on how to install VoIP Monitoring Manager licenses.

Microsoft SQL 2000 Database

During VoIP Monitoring Manager installation, you can install your own database if you do not want to install the MSDE database provided on the VoIP Monitoring Manager CD. If you are installing the Microsoft SQL 2000 database, it is recommended that you install it on the same server as the VoIP Monitoring Manager server to ensure optimal performance.

If VoIP Monitoring Manager with the MSDE database is already installed on the server, and you plan to install the Microsoft SQL 2000 database on the same server, it is recommended that you upgrade the MSDE database using the Microsoft SQL 2000 installer. An upgrade installation performed in this way will preserve pre-existing data.

VoIP Monitoring Manager System Requirements

[Table 5](#) and [Table 6](#) provide the minimum system requirements to install and operate the VoIP Monitoring Manager Server and Client software.

Table 5: VoIP Monitoring Manager Server Requirements

Component	Required	Comments
Operating System	Microsoft Windows 2003 Standard Edition server, Microsoft Windows 2003 Enterprise Edition server, Microsoft Windows 2000 server, or Microsoft Windows XP Professional	Only English operating systems are supported.
Processor	2.8 GHz Pentium® 4	A maximum of two processors is supported.
Hard Drive	40 GB	
Memory	1.5 GB RAM	
Network Connectivity	TCP/IP 100 Mbit Network Card	Only one network interface is supported. Dual network interface cards (NICs) or additional software network interfaces, such as a VPN interface, are not supported.
Modem	56K modem for remote access	
CD-ROM Drive		Required for installation.
Monitor	SVGA 1024 X 768 display	
SNMP Agent	The Simple Network Management Protocol (SNMP) Agent is the Windows Service that runs on your computer. It is provided with the Windows operating system CD but is not installed by default. When installing the VoIP Monitoring Manager, you will be prompted to install it, if it is not already installed.	
Extra Software	Anti-virus software pcAnywhere	Required for Avaya support. pcAnywhere is required for remote access by Avaya Services.
1 of 2		

Table 5: VoIP Monitoring Manager Server Requirements (continued)

Component	Required	Comments
Web Browser	Internet Explorer 6.0	Required for access to the Integrated Management Launch Page and web-based clients.
Integration with HP OpenView Network Node Manager	HP OpenView 7.0.1 or HP OpenView 7.5.	HP OpenView is not included on any Avaya Integrated Management CD. Customers must purchase, install, and maintain HP OpenView. While Avaya services support Integrated Management when installed over HP OpenView, they do not support the HP OpenView product itself.
Port	The client and server software communicate using Java Remote Method Invocation (RMI), and use port 1099 on the machine on which the server is running. If this port is unavailable, the server will attempt to use the following ports: 49177, 51173, or 63006. Although it is unlikely that all of these ports will be in use on a single machine, ensure that at least one of these ports is available.	
2 of 2		

Table 6: VoIP Monitoring Manager Client Requirements

Component	Required	Comments
Operating System	Microsoft Windows 2000, Windows XP Professional, or Windows 2003.	Only English operating systems are supported.
Processor	600 MHz Pentium®	
Hard Drive	1 GB	
Memory	256 MB RAM	
Monitor	SVGA 1024 X 768 display	
Network Connectivity	TCP/IP 10/100 Network Card	
Modem	56K Modem	May be required for remote access to the client PC.
CD-ROM Drive		Required for installation.
Web Browser	Internet Explorer 6.0	Required to access the Integrated Management Launch Page and web-based client.

Installing the Software

Use this procedure to install VoIP Monitoring Manager Server, VoIP Monitoring Manager Client, and WebLM Server on the Windows server. The procedure to install or upgrade Avaya VoIP Monitoring Manager is generally the same.

Note:

If you are upgrading Avaya VoIP Monitoring Manager and there are previous releases of other Integrated Management applications on the Windows server, you must either upgrade the other Integrated Management applications to this version of Avaya VoIP Monitoring Manager, or install the new version of Avaya VoIP Monitoring Manager on another Windows server.

1. Ask all users to log off the system.
2. Close all open windows and applications.
3. Insert the **Avaya Integrated Management, VoIP Monitoring Manager 3.1 CD** into the CD-ROM drive.

The Avaya Integrated Management VoIP Monitoring Manager window appears. It provides the main menu.

Note:

Install Acrobat Reader if it is not already installed on the computer.

4. Click **Install VoIP Monitoring Manager**.

The Welcome dialog box appears.

Note:

If Network Management is installed on the server, a message appears stating if you are supporting a network of more than 2000 IP endpoints/devices, it is recommended that VoIP Monitoring Manager and the Network Management applications be installed on separate servers. To continue with the installation, click the **Yes** button. If it is necessary to install VoIP Monitoring Manager on another server, click the **No** button to exit the installation.

5. Click the **Next** button.

The License Agreement dialog box appears.

6. Read the license agreement. If you accept the license agreement, click the **I accept the terms of the license agreement** option button, and then click the **Next** button.

Note:

You cannot install VoIP Monitoring Manager unless you accept the license agreement.

The Choose Destination Location dialog box appears. By default, the application will be installed in **c:\Program Files\Avaya**.

7. Perform one of the following steps:

- To install the applications in the default folder, click the **Next** button.
- To change the folder where the applications will be installed, click the **Change** button, specify the folder you want to use, and then click the **Next** button.

The Select Features dialog box appears. This dialog box displays the applications you can install. See [WebLM License Server](#) on page 41 for information about the WebLM application.

8. Make sure the applications you want to install are selected. By default, VMM Server, WebLM License Server, and VMM Client are selected. It is recommended that you install the VMM Client with the VMM Server.

9. Click the **Next** button.

One of the following appears:

- If IIS (Microsoft's Web Server) is detected on the server, the IIS Installation Detected dialog box appears. Enter the new port number on which IIS should run, and then click the **Next** button. By default, the new port is 8989.

The Apache Server Information dialog box appears. Go to Step [10](#).

Note:

If the Apache server is already installed on this server, you are not prompted for the Apache server information. Instead, the Avaya Integrated Management Launch Page Server dialog box appears. Go to Step [12](#).

- If IIS is not detected on the server, the Apache Server Information dialog box appears. Go to Step [10](#).

Note:

If the Apache server is already installed on this server, you are not prompted for the Apache server information. Instead, the Avaya Integrated Management Launch Page Server dialog box appears. Go to Step [12](#).

10. Enter the Network Domain, Server Name, and Administrator's e-mail address. By default, Apache HTTP server programs and short cuts will be installed for all users. Choose to install only for current user if desired.

Note:

Network Domain, Server Name, and Administrator's e-mail fields must be completed. The Administrator's e-mail address allows the system to notify the administrator if problems occur during the Apache installation.

11. Click the **Next** button.

The Avaya Integrated Management Launch Page Server dialog box appears.

12. Enter the IP Address of your Avaya Integrated Management Launch Page Server, and then click the **Next** button.

The Install New Database or Use an Existing Database dialog box appears.

13. Based on whether you are installing the MSDE database that is included on the VoIP Monitoring Manager CD, or using a database already installed, do one of the following:

- If you want to install the MSDE database that is included on the VoIP Monitoring Manager CD, continue with Step [14](#).
- If you want to use a database that is already installed, go to [Installing VoIP Monitoring Manager With a Database Already Installed](#) on page 51.

14. Select **Install MSDE from this CD**, and then click the **Next** button.

The MSDE Service Pack Installation Steps dialog box appears.

Note:

It is recommended that you complete the VoIP Monitoring Manager installation, and then download and install the MSDE Service Pack.

If you already have an earlier version of MSDE and would like to upgrade to MSDE 2000 Service Pack 3a (SP3a), you will need to use the SQL Server 2000 SP3a download.

15. Click the **Print** button to print a copy of the MSDE Service Pack Installation Steps.

16. Click the **Next** button.

A message appears stating the MSDE database will be installed on Windows with Mixed Mode Security.

17. Click the **OK** button.

The Database Login Information dialog box appears. The MSDE Administrative login is provided.

18. Enter the MSDE Administrator password, confirm the password, and then click the **Next** button.

Note:

After you set the MSDE Administrator password, make a note of it in a secure location. Do not change the MSDE Administrator login provided.

- If you are installing the WebLM License Server, the WebLM Port Information dialog box appears. Go to Step [19](#).
- If you are not installing the WebLM License Server, the WebLM Server Information dialog box appears. Perform one of the following steps:
 - If you have licenses to activate VoIP Monitoring Manager beyond the 90-day trial period, enter the IP address of the server on which the WebLM License Server application is installed, and then click the **Next** button.

The WebLM Port Information dialog box appears. Go to Step [19](#).

- If you do not have licenses for VoIP Monitoring Manager, leave the IP address field blank, and then click the **Next** button.

A message appears stating you have not entered a WebLM IP address and VoIP Monitoring Manager will run as an evaluation version. Click the **OK** button.

The Start Copying Files dialog box appears. Go to Step [20](#).

19. Enter the port number on which the WebLM License Server should run, and then click the **Next** button. The default port is 3999.

The Start Copying Files dialog box appears.

20. Review the setup information, and then click the **Next** button.

The installation status bar appears while files are configured and installed. When the installation is complete, a message appears stating not to forget to configure Avaya Communication Manager so that it is pointing towards the VoIP Monitoring Manager server.

21. Click the **OK** button.

The InstallShield Wizard Complete dialog box appears.

22. Remove the CD from the CD-ROM drive.

23. Click the **Finish** button to restart the server.

24. Be sure to download and install the latest MSDE Service Pack as described in Steps [14](#) and [15](#).

Initial configuration tasks must be performed the first time you use VoIP Monitoring Manager. See *Avaya VoIP Monitoring Manager Release 3.1 Configuration*, document number 555-233-510, for procedures you must perform the first time you run the software.

Installing VoIP Monitoring Manager With a Database Already Installed

Use this procedure if you want to use a local or remote database that is already installed. This procedure also includes installation of the WebLM server application.

1. See [Installing the Software](#) on page 48 and perform Steps 1 through 12. At Step 12, the Install New Database or Use an Existing Database dialog box appears.

2. Select **Use a database currently installed**, and click the **Next** button.

The Where is Your Database Located? dialog box appears.

3. Based on whether the database is installed on this server or another server, perform one of the following steps:

- If the database is installed on this machine, select **Locally, on this machine**, and click the **Next** button.

The Does the Database Need to be Initialized? dialog box appears. Go to Step [4](#).

- If the database is installed on another machine, select **Remotely, on another machine**, and click the **Next** button.

The Database Server IP Address dialog box appears.

Enter the IP Address of the database location, and click the **Next** button.

The Does the Database Need to be Initialized? dialog box appears. Go to Step [4](#).

4. Perform one of the following steps:

- If yes, select **Yes, it needs to be initialized**, and click the **Next** button.

The Configure Existing Database dialog box appears. Back up the existing database as recommended. After the database is backed up, click the **Next** button.

- If you are installing the WebLM License Server, the WebLM Port Information dialog box appears. Go to Step [5](#).
- If you are not installing the WebLM License Server, the WebLM Server Information dialog box appears. Perform one of the following steps:

- If you have licenses to activate VoIP Monitoring Manager beyond the 90-day trial period, enter the IP address of the server on which the WebLM License Server application is installed, and then click the **Next** button.

The WebLM Port Information dialog box appears. Go to Step [5](#).

- If you do not have licenses for VoIP Monitoring Manager, leave the IP address field blank, and then click the **Next** button.

A message appears stating you have not entered a WebLM IP address and VoIP Monitoring Manager will run as an evaluation version. Click the **OK** button.

The Start Copying Files dialog box appears. Go to Step [6](#).

- If no, select **No, it has existing VoIP data**, and click the **Next** button.

The Update Existing Database dialog box appears. Back up the existing database as recommended. After the database is backed up, click the **Next** button.

- If you are installing the WebLM License Server, the WebLM Port Information dialog box appears. Go to Step [5](#).
- If you are not installing the WebLM License Server, the WebLM Server Information dialog box appears. Perform one of the following steps:
 - If you have licenses to activate VoIP Monitoring Manager beyond the 90-day trial period, enter the IP address of the server on which the WebLM License Server application is installed, and then click the **Next** button.

The WebLM Port Information dialog box appears. Go to Step [5](#).

- If you do not have licenses for VoIP Monitoring Manager, leave the IP address field blank, and then click the **Next** button.

A message appears stating you have not entered a WebLM IP address and VoIP Monitoring Manager will run as an evaluation version. Click the **OK** button.

The Start Copying Files dialog box appears. Go to Step [6](#).

5. Enter the port number on which the WebLM License Server should run, and click the **Next** button. The default is 3999.

The Start Copying Files dialog box appears.

6. Review the setup information, and then click the **Next** button.

The installation status bar appears while files are configured and installed. When the installation is complete, a message appears stating not to forget to configure Avaya Communication Manager so that it is pointing towards the VoIP Monitoring Manager server.

7. Click the **OK** button.

The InstallShield Wizard Complete dialog box appears.

8. Remove the CD from the CD-ROM drive.

9. Click the **Finish** button to restart the server.

Initial configuration tasks must be performed the first time you use VoIP Monitoring Manager. See *Avaya VoIP Monitoring Manager Release 3.1 Configuration*, document number 555-233-510, for procedures you must perform the first time you run the software.

Installing the Client Software

Use this procedure to install or upgrade the VoIP Monitoring Manager Client. The VoIP Monitoring Manager Client may be installed on the same PC as the VoIP Monitoring Manager Server, or it may be installed on another PC on the network.

1. Ask all users to log off the system.
2. Close all open windows and applications.
3. Insert the **Avaya Integrated Management, VoIP Monitoring Manager 3.1** CD into the CD-ROM drive.

The Avaya Integrated Management, VoIP Monitoring Manager window appears. It provides the main menu.

Note:

Install Acrobat Reader if it is not already installed on the computer.

4. Click **Install VoIP Monitoring Manager**.

The Welcome dialog box appears.

5. Click the **Next** button.

The License Agreement dialog box appears.

6. Read the license agreement. If you accept the license agreement, click the **I accept the terms of the license agreement** option button, and then click the **Next** button.

Note:

You cannot install VoIP Monitoring Manager unless you accept the license agreement.

The Choose Destination Location dialog box appears. By default, the application will be installed in **c:\Program Files\Avaya**.

7. Perform one of the following steps:

- To install the applications in the default folder, click the **Next** button.
- To change the folder where the applications will be installed, click the **Change** button, specify the folder you want to use, and then click the **Next** button.

The Select Features dialog box appears. By default, all components are selected.

8. Click the check boxes for **VoIP Monitoring Manager Server** and **WebLM** to deselect them. Only **VoIP Monitoring Manager Client** should be selected. Click the **Next** button.

The Avaya Integrated Management Launch Page Server dialog box appears.

9. Enter the IP Address of your Avaya Integrated Management Launch Page Server, and then click the **Next** button.

The VoIP Monitoring Manager Server IP Address dialog box appears.

10. Enter the IP address of your VoIP Monitoring Manager Server, and click the **Next** button.
The Start Copying Files dialog box appears.
11. Review the setup information and then click the **Next** button.
The installation status bar appears while files are configured and installed. When the installation is complete, the InstallShield Wizard Complete dialog box appears.
12. Remove the CD from the CD-ROM drive.
13. Click the **Finish** button to restart the computer.

Installing VoIP Monitoring Manager Licenses

After the WebLM License Server is installed, you can install the VoIP Monitoring Manager licenses so that you can use VoIP Monitoring Manager beyond the 90-day trial period.

Note:

To purchase the licenses, contact your Avaya representative.

To install VoIP Monitoring Manager licenses, follow these steps:

1. Select **Start > Programs > Avaya > Avaya Integrated Management WebLM Server Login**.

The Web License Manager login page appears.

2. In the **User Name** field, enter the default user name **admin**.
3. In the Password field, enter the default password, **weblmadmin**.
4. Click the **Login** button.

Note:

See the administrator for the WebLM License Server for the login and password to use after you log in for the first time using the default user name and password.

5. Click **Install Licenses** in the left-hand panel of the window.
6. Click the **Browse** button and select the license files you want to install.
7. Click the **Install** button to install the selected license files.

Note:

An error message appears if the license file name is invalid, belongs to another license server, or is already installed on the current license server.

8. Click **Licensed Products > IMMS** in the left-hand panel to display the license details.

Post-Installation Tasks

After installing Avaya VoIP Monitoring Manager, you must complete the following post-installation tasks.

1. Check for a valid community name. (See [Checking for a Valid Community Name](#) on page 56.)
2. Configure two Avaya Communication Manager administration forms—the IP Network Region form and the System Parameters IP-Options form. (See [Configuring the Avaya Communication Manager Administration Forms](#) on page 57.)
3. Configure the RTCP Listen Port for the Avaya VoIP Monitoring Manager Server. The RTCP Listen Port must match the default RTCP monitor server port administered on the Avaya Communication Manager Server. The default is 5005. (See [Configuring the RTCP Listen Port](#) on page 60.)

Checking for a Valid Community Name

Avaya VoIP Monitoring Manager Server requires a Windows SNMP service community name that has read-write community rights. By default, the community name with read-write community rights in Windows SNMP service is **private**. However, this setting may have been changed. Read-write community rights are required for loading, changing, and saving configuration options.

To check for a valid community name on the PC on which Avaya VoIP Monitoring Manager Server is installed, follow these steps:

1. Click **Start > Settings > Control Panel**.
2. Select **Administrative Tools**.
3. Select **Services** from the list in the **Name** column.
4. Scroll down to **SNMP Service**.
5. Right-click on **SNMP Service** and select **Properties** from the context menu.
6. Select the **Security** tab.

The Accepted community names list box displays the Windows SNMP service community names.

7. Be sure to remember the community name that has read-write community rights. After you install Avaya VoIP Monitoring Manager Server, you must assign this community name in Avaya VoIP Monitoring Manager Server. The community name in Avaya VoIP Monitoring Manager Server must match the community name defined in Windows SNMP service.

Note:

Avaya VoIP Monitoring Manager will attempt to initially connect using the community name **private**. For security reasons, it is recommended that you choose a different community name.

Configuring the Avaya Communication Manager Administration Forms

There are two Avaya Communication Manager administration forms—the System Parameters IP-Options form and the IP Network Region form—that you administer so that the server running Avaya Communication Manager sends RTCP reports to the RTCP Monitor. When you administer the System Parameters IP-Options form, the IP Network Region forms are set, by default, with the same values. You can then, optionally, make changes to a network region by changing the region's IP Network Region form.

Use the following SAT commands to make changes to the values on the forms:

- **change ip-network-region <x>** where x is a number from 1 to 250.
- **change system-parameter ip-options**

Configuring the IP Network Region Form

[Figure 1](#) shows an IP Network Region form. To configure this form, follow these steps:

1. Set the RTCP Reporting Enabled? field to y (yes).
2. Set the Use Default Server Parameters? field to y (yes). This indicates that this network region uses the default values specified on the System Parameters IP-Options form.

Figure 1: IP Network Region Form

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
IP NETWORK REGION																		
Region: 1																		
Location: <input type="text"/>				Authoritative Domain: <input type="text"/>														
Name: <input type="text"/>																		
MEDIA PARAMETERS										Intra-region IP-IP Direct Audio: <input type="text" value="yes"/>								
Codec Set: <input type="text" value="1"/>										Inter-region IP-IP Direct Audio: <input type="text" value="yes"/>								
UDP Port Min: <input type="text" value="2048"/>										IP Audio Hairpinning? <input type="text" value="y"/>								
UDP Port Max: <input type="text" value="3028"/>										RTCP Reporting Enabled? <input type="text" value="y"/>								
DIFFSERV/TOS PARAMETERS										RTCP MONITOR SERVER PARAMETERS								
Call Control PHB Value: <input type="text" value="46"/>										Use Default Server Parameters? <input type="text" value="y"/>								
Audio PHB Value: <input type="text" value="46"/>																		
Video PHB Value: <input type="text" value="26"/>																		
802.1P/Q PARAMETERS																		
Call Control 802.1p Priority: <input type="text" value="6"/>										AUDIO RESOURCE RESERVATION PARAMETERS								
Audio 802.1p Priority: <input type="text" value="6"/>										RSVP Enabled? <input type="text" value="n"/>								
H.323 IP ENDPOINTS																		
H.323 Link Bounce Recovery? <input type="text" value="y"/>																		
Idle Traffic Interval (sec): <input type="text" value="20"/>																		
Keep-Alive Interval (sec): <input type="text" value="5"/>																		
Keep-Alive Count: <input type="text" value="5"/>																		

In some cases, you may not want to set the Default Parameters to yes. Set the field to n (no) and specify the IP address of the Windows PC running the server for that network region.

An example of when you might not want to set the Default Parameters to yes is if you have multiple servers installed on a large system in order to reduce the network traffic between a set of endpoints and the RTCP Monitor (for example, low bandwidth link between endpoints in one network region and a remote RTCP Monitor). The network traffic resulting from RTCP reports being sent from the endpoints to the RTCP Monitor is usually low, less than 40 bytes per second per currently active VoIP call (RTP session). Therefore, it is usually unnecessary to have multiple RTCP Monitors.

If multiple Servers are installed on the system, the endpoints in each network region can be configured to send their RTCP reports to different RTCP Monitors.

Configuring the System Parameters IP-Options Form

[Figure 2](#) shows a Systems Parameters IP-Options form. To configure this form, locate the heading `RTCP MONITOR SERVER` and follow these steps:

1. Set the Default Server IP Address to the address of the Windows PC running the VoIP Monitoring Manager Server.
2. Set the Default RTCP Report Period (secs) to 10. This will reduce the amount of data that needs to be stored and thereby help ensure the MSDE or MSSQL database does not reach its limit too quickly.

Figure 2: System Parameters IP-Options Form

The screenshot shows a window titled "IP-OPTIONS SYSTEM PARAMETERS" with a tabbed interface. The "2" tab is selected. The form contains the following sections and fields:

- IP MEDIA PACKET PERFORMANCE THRESHOLDS**
 - Roundtrip Propagation Delay (ms): High: 800, Low: 400
 - Packet Loss (%): High: 40, Low: 15
 - Ping Test Interval (sec): 20
 - Number of Pings Per Measurement Interval: 10
- RTCP MONITOR SERVER**
 - Default Server IP Address: []-[]-[]-[]
 - Default Server Port: 5005
 - Default RTCP Report Period(secs): 5
- AUTOMATIC TRACE ROUTE ON**
 - Link Failure? ☒
- H.248 MEDIA GATEWAY**
 - Link Loss Delay Timer (min): 5
- H.323 IP ENDPOINT**
 - Link Loss Delay Timer (min): 5
 - Primary Search Time (sec): 75
 - Periodic Registration Timer (min): 20

Configuring the RTCP Listen Port

The RTCP Listen Port administered in the Avaya VoIP Monitoring Manager Server must match the default RTCP monitor server port administered on the Avaya Communication Manager Server. Use this procedure to change the RTCP Listen Port on the VoIP Monitoring Manager Server to match the port number administered on the Avaya Communication Manager Server. See [Configuring the System Parameters IP-Options Form](#) on page 59 for information on how to determine the default server port for the RTCP monitor server on the Avaya Communication Manager Server.

To configure the RTCP Listen Port in the Avaya VoIP Monitoring Manager Server, follow these steps:

1. Access the VoIP Monitoring Manager Server interface. See *Avaya VoIP Monitoring Manager Release 3.1 Configuration*, document number 555-233-510.

2. On the **Edit** menu, click **Options**.

The Server Options dialog box displays.

3. Click the **RTCP** tab and enter the new RTCP Listen Port. Make sure this RTCP Listen Port matches the default server port for the RTCP monitor server administered on the Avaya Communication Manager Server. The default is 5005.
4. Click the **OK** button to save the changes and close the dialog box or the **Cancel** button to close without saving.

The VoIP Monitoring Manager Server will reset the properties and attempt to re-connect to the Windows SNMP Agent based on the new properties.

Note:

Changing the RTCP port displays a warning indicating it must match the port configured on the Avaya Communication Manager Server. See <http://www.iana.org/assignments/port-numbers> and your Avaya Communication Manager documentation. It is unusual to change the listen port from the default of 5005. The default should be suitable in most situations.

Uninstalling the Software

Use this procedure to uninstall VoIP Monitoring Manager server and client software.

1. Select **Start > Control Panel**.

The Control Panel window appears.

2. Click on **Add or Remove Programs**.

The Add or Remove Programs window appears.

3. Click on **Avaya Integrated Management VoIP Monitoring Manager 3.1**.

4. Click the **Remove** button.

A dialog box appears prompting you to confirm that you want to remove the application.

5. Click the **Yes** button.

If the MSDE database was installed with VoIP Monitoring Manager, a message informs you that the MSDE database will be uninstalled. Be sure to back up VoIP Monitoring Manager data before continuing with this procedure.

6. Click the **OK** button.

A message appears and asks if you want to uninstall Apache Tomcat.

7. Click the **Yes** button.

A message appears and asks if you want to uninstall Sun's JDK.

8. Click the **Yes** button.

The Uninstall Complete dialog box appears.

9. Click the **Yes, I want to restart my computer now** option button, and then click the **Finish** button.

Chapter 7: Avaya Mailbox Manager

About Mailbox Manager

Mailbox Manager for the Avaya S3400 Message server is a Windows interface for performing moves, adds, and changes on the Message Storage Server (MSS) component. The software maintains an off-line database of your subscriber and class of service data. You make your changes to subscribers and classes of service in this interface, and it sends the changes to your MSS.

Launching Mailbox Manager

The Avaya Mailbox Manager option is available from the Launch Products page, which is on the Avaya Integrated Management Launch Page. In order to launch Mailbox Manager from the Launch Products page, you must:

1. Install Avaya Site Administration and/or Avaya Voice Announcement Manager which are provided on the Administration Tools CD. (See [Chapter 4: Administration Tools Installation](#).) The installation of at least one of these products automatically installs the components required to launch the Mailbox Manager from the Avaya Integrated Management Launch Page.
2. Install Avaya Mailbox Manager on your PC. Installation software for Mailbox Manager is included on the Avaya Modular Messaging Installation CD that comes with the Avaya S3400. Follow the single-user instructions provided in the *Mailbox Manager Getting Started Guide*.
3. Complete the licensing procedure as described in "[Licensing Mailbox Manager](#) on page 64."

Licensing Mailbox Manager

When you install Avaya Mailbox Manager, a single-user license is created. If your organization also manages other Avaya legacy message servers that are supported by Mailbox Manager (for example, Octel 250/350, Octel 200/300, or Intuity AUDIX) you may already have Mailbox Manager licenses for those as well. You can combine the licenses for these systems into one license and manage them from one interface if you upgrade those licenses to Mailbox Manager 5.0.

Note:

If you plan to use Mailbox Manager to manage your Messaging Services system along with Octel 250/350, Octel 200/300, or Intuity AUDIX system, then you cannot run Mailbox Manager from the Messaging Application software.

To get a combined license for all of your Avaya message servers, do the following:

1. Install Mailbox Manager for your Avaya S3400 by following the single-user instructions provided in the *Mailbox Manager Getting Started Guide*.
2. Locate your license file **C:\MBMData\Config\Config.2nl**.
3. Send an e-mail to **license@unimax.com** requesting the license. You will need to include a copy of your license file and identifying numbers for your legacy systems, as follows:
 - Octel 200/300 with system software 2.0 or newer — system serial number and current system software version.
 - Octel 250/350 with system software 2.0 or newer — system serial number (also known as VPMOD serial number) and current system software version.
 - Intuity AUDIX with system software 4.4 or newer — system serial number, current system software version, and model type. (MAP 40 and MAP 100 were sold with bundled licenses. MAP 5 is supported by Mailbox Manager but did not include a license.)

Appendix A: Legal Information

Overview

This appendix contains information related to

- Avaya Network Management Enterprise Server Software
- Avaya Provisioning and Installation Manager Software

Avaya Network Management Enterprise Server Software

This section contains information related to the Avaya Network Management Enterprise Server Software (as defined below) and Documentation (“Product”). Documentation means this document and Avaya’s information manuals in printed or electronic form containing operating instructions and performance specifications that Avaya or its suppliers generally make available to users of its products, and which Avaya delivers to End User with the Products. “End User” means any customer of Avaya or its authorized resellers, or any end user of the Product. See the Software and Documentation DVD/CD inserts for additional legal and licensing information. This section includes:

- Notice
- Disclaimer
- Warranty
- License
- Copyright
- Security and virus disclaimer
- Trademarks

Notice

Changes and corrections to the information in this document may be incorporated in future releases.

Disclaimer

Avaya, its affiliates or subsidiaries (“Avaya”) are not responsible for any modifications, additions or deletions to the original published version of the Documentation unless such modifications, additions or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants, directors, officers, and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to the Documentation to the extent made by the End User.

Warranty

Avaya provides a limited warranty on the Product. Refer to your customer sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language as well as information regarding support for the Product, while under warranty, is available through the following web site: <http://support.avaya.com>.

License

USE OR INSTALLATION OF THE PRODUCT INDICATES THE END USER'S ACCEPTANCE OF THE GENERAL LICENSE TERMS AVAILABLE ON THE AVAYA WEB SITE AT: <http://support.avaya.com/LicenseInfo>. (“GENERAL LICENSE TERMS”). DO NOT USE THE PRODUCT IF YOU DO NOT WISH TO BE BOUND BY THE GENERAL LICENSE TERMS. IN ADDITION TO THE GENERAL LICENSE TERMS, THE FOLLOWING LICENSE TERMS AND RESTRICTIONS WILL APPLY TO THE PRODUCT.

Avaya grants End User a license within the scope of the license types described below. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a different number of licenses or units of capacity is specified in the Documentation or other materials available to End User. “Designated Processor” means a single stand-alone computing device. “Server” means a Designated Processor that hosts a software application to be accessed by multiple users. “Software” means the computer programs in object code, originally licensed by Avaya and ultimately utilized by End User, whether as stand-alone products or pre-installed on Hardware. “Hardware” means the standard hardware products, originally sold by Avaya and ultimately utilized by End User.

Designated System(s) License (DS). End User may install and use each copy of the Software only on a number of Designated Processors up to the number indicated in the order. Avaya may require the Designated Processor(s) to be identified in the order by type, serial number, feature key, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Concurrent User License (CU). End User may install and use the Software on multiple Designated Processors or one or more Servers, so long as only the licensed number of Units are accessing and using the Software at any given time. A “Unit” means the unit on which Avaya, at its sole discretion, bases the pricing of its licenses and can be, without limitation, an agent, port or user, an e-mail or voice mail account in the name of a person or corporate function (e.g., webmaster or helpdesk), or a directory entry in the administrative database utilized by the Product that permits one user to interface with the Software. Units may be linked to a specific, identified Server.

Shrinkwrap License (SR). With respect to Software that contains elements provided by third party suppliers, End User may install and use the Software in accordance with the terms and conditions of the “shrinkwrap” or “clickwrap” license accompanying the Software (“Shrinkwrap License”). The text of the Shrinkwrap License will be available from Avaya upon End User's request (see “Copyright” below for more information).

Copyright

Except where expressly stated otherwise, the Product is protected by copyright and other laws respecting proprietary rights. Unauthorized reproduction, transfer, and or use can be a criminal, as well as a civil, offense under the applicable law. Certain Software programs or portions thereof included in the Product may contain software distributed under third party agreements (“Third Party Components”), which may contain terms that expand or limit rights to use certain portions of the Product (“Third Party Terms”). Information identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on Avaya's web site at <http://support.avaya.com/ThirdPartyLicense/>.

The disclaimers of warranties and limitations of liability set forth in the Third Party Terms do not affect any express warranty or limitation of liability that may be provided to you by Avaya pursuant to the license terms covering the Product contained in a separate written agreement between you and Avaya. To the extent there is a conflict between the General License Terms or your customer sales agreement and any Third Party Terms, the Third Party Terms shall prevail solely for such Third Party Components.

Security and Virus Disclaimer

End User's decision to acquire products from third parties is End User's sole responsibility, even if Avaya helps End User identify, evaluate or select them. Avaya is not responsible for, and will not be liable for, the quality or performance of such third party products or their suppliers.

ALL INFORMATION IS BELIEVED TO BE CORRECT AT THE TIME OF PUBLICATION AND IS PROVIDED "AS IS". AVAYA DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND FURTHERMORE, AVAYA MAKES NO REPRESENTATIONS OR WARRANTIES THAT THE STEPS RECOMMENDED WILL ELIMINATE SECURITY OR VIRUS THREATS TO END USER' SYSTEMS. IN NO EVENT SHALL AVAYA BE LIABLE FOR ANY DAMAGES WHATSOEVER ARISING OUT OF OR IN CONNECTION WITH THE INFORMATION OR RECOMMENDED ACTIONS PROVIDED HEREIN, INCLUDING DIRECT, INDIRECT, CONSEQUENTIAL DAMAGES, LOSS OF BUSINESS PROFITS OR SPECIAL DAMAGES, EVEN IF AVAYA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Avaya does not warrant that this Product is immune from or will prevent unauthorized use of telecommunication services or facilities accessed through or connected to it. Avaya is not responsible for any damages or charges that result from either unauthorized uses or from incorrect installations of the security patches that are made available from time to time. Suspected security vulnerabilities with Avaya products should be reported to Avaya by sending mail to securityalerts@avaya.com.

Trademarks

All trademarks identified by ® and ™ are registered trademarks or trademarks of Avaya Inc. All other trademarks are the property of their respective owners.

2006 Avaya Inc. All rights reserved.

Avaya Provisioning and Installation Manager Software

This section contains information related to the Avaya Provisioning and Installation Manager Software (as defined below) and Documentation ("Product"). "Documentation" means this document and Avaya's information manuals in printed or electronic form containing operating instructions and performance specifications that Avaya or its suppliers generally make available to users of its products, and which Avaya delivers to End User with the Products. "End User" means any customer of Avaya or its authorized resellers, or any end user of the Product. See the Software and Documentation DVD/CD inserts for additional legal and licensing information. This section includes:

- Notice
- Disclaimer
- Warranty
- License
- Copyright
- Security and virus disclaimer
- Trademarks

Notice

Changes and corrections to the information in this document may be incorporated in future releases.

Disclaimer

Avaya, its affiliates or subsidiaries ("Avaya") are not responsible for any modifications, additions or deletions to the original published version of the Documentation unless such modifications, additions or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants, directors, officers, and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to the Documentation to the extent made by the End User.

Warranty

Avaya provides a limited warranty on the Product. Refer to your customer sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language as well as information regarding support for the Product, while under warranty, is available through the following web site: <http://support.avaya.com>.

License

USE OR INSTALLATION OF THE PRODUCT INDICATES THE END USER'S ACCEPTANCE OF THE GENERAL LICENSE TERMS AVAILABLE ON THE AVAYA WEB SITE AT: <http://support.avaya.com/LicenseInfo>. ("GENERAL LICENSE TERMS"). DO NOT USE THE PRODUCT IF YOU DO NOT WISH TO BE BOUND BY THE GENERAL LICENSE TERMS. IN ADDITION TO THE GENERAL LICENSE TERMS, THE FOLLOWING LICENSE TERMS AND RESTRICTIONS WILL APPLY TO THE PRODUCT.

Avaya grants End User a license within the scope of the license types described below. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a different number of licenses or units of capacity is specified in the Documentation or other materials available to End User. "Designated Processor" means a single stand-alone computing device. "Server" means a Designated Processor that hosts a software application to be accessed by multiple users. "Software" means the computer programs in object code, originally licensed by Avaya and ultimately utilized by End User, whether as stand-alone products or pre-installed on Hardware. "Hardware" means the standard hardware products, originally sold by Avaya and ultimately utilized by End User.

Designated System(s) License (DS). End User may install and use each copy of the Software only on a number of Designated Processors up to the number indicated in the order. Avaya may require the Designated Processor(s) to be identified in the order by type, serial number, feature key, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Concurrent User License (CU). End User may install and use the Software on multiple Designated Processors or one or more Servers, so long as only the licensed number of Units are accessing and using the Software at any given time. A "Unit" means the unit on which Avaya, at its sole discretion, bases the pricing of its licenses and can be, without limitation, an agent, port or user, an e-mail or voice mail account in the name of a person or corporate function (e.g., webmaster or helpdesk), or a directory entry in the administrative database utilized by the Product that permits one user to interface with the Software. Units may be linked to a specific, identified Server.

Database License (DL). End User may install and use each copy of the Software on one Server or on multiple Servers provided that each of the Servers on which the Software is installed communicate with no more than a single instance of the same database.

Shrinkwrap License (SR). With respect to Software that contains elements provided by third party suppliers, End User may install and use the Software in accordance with the terms and conditions of the “shrinkwrap” or “clickwrap” license accompanying the Software (“Shrinkwrap License”). The text of the Shrinkwrap License will be available from Avaya upon End User's request (see “Copyright” below for more information).

Copyright

Except where expressly stated otherwise, the Product is protected by copyright and other laws respecting proprietary rights. Unauthorized reproduction, transfer, and or use can be a criminal, as well as a civil, offense under the applicable law. Certain Software programs or portions thereof included in the Product may contain software distributed under third party agreements (“Third Party Components”), which may contain terms that expand or limit rights to use certain portions of the Product (“Third Party Terms”). Information identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on Avaya’s web site at <http://support.avaya.com/ThirdPartyLicense/>.

The disclaimers of warranties and limitations of liability set forth in the Third Party Terms do not affect any express warranty or limitation of liability that may be provided to you by Avaya pursuant to the license terms covering the Product contained in a separate written agreement between you and Avaya. To the extent there is a conflict between the General License Terms or your customer sales agreement and any Third Party Terms, the Third Party Terms shall prevail solely for such Third Party Components.

Security and Virus Disclaimer

End User's decision to acquire products from third parties is End User's sole responsibility, even if Avaya helps End User identify, evaluate or select them. Avaya is not responsible for, and will not be liable for, the quality or performance of such third party products or their suppliers.

ALL INFORMATION IS BELIEVED TO BE CORRECT AT THE TIME OF PUBLICATION AND IS PROVIDED “AS IS”. AVAYA DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND FURTHERMORE, AVAYA MAKES NO REPRESENTATIONS OR WARRANTIES THAT THE STEPS RECOMMENDED WILL ELIMINATE SECURITY OR VIRUS THREATS TO END USER’ SYSTEMS. IN NO EVENT SHALL AVAYA BE LIABLE FOR ANY DAMAGES WHATSOEVER ARISING OUT OF OR IN CONNECTION WITH THE INFORMATION OR RECOMMENDED ACTIONS PROVIDED HEREIN, INCLUDING DIRECT, INDIRECT, CONSEQUENTIAL DAMAGES, LOSS OF BUSINESS PROFITS OR SPECIAL DAMAGES, EVEN IF AVAYA HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Legal Information

Avaya does not warrant that this Product is immune from or will prevent unauthorized use of telecommunication services or facilities accessed through or connected to it. Avaya is not responsible for any damages or charges that result from either unauthorized uses or from incorrect installations of the security patches that are made available from time to time. Suspected security vulnerabilities with Avaya products should be reported to Avaya by sending mail to securityalerts@avaya.com.

Trademarks

All trademarks identified by ® and ™ are registered trademarks or trademarks of Avaya Inc. All other trademarks are the property of their respective owners.

2006 Avaya Inc. All rights reserved.

Index

Symbols

>, meaning of in text [8](#)

A

Administration Tools CD [27](#)

Avaya

support resources [8](#)

support web site [12](#)

Avaya Communication Manager

user license [13](#)

Avaya Integrated Management Launch Page Server . [29](#)

Avaya Site Administration [27](#), [63](#)

Avaya Voice Announcement Manager [27](#), [63](#)

B

bold text, meaning of [8](#)

C

contact information for Avaya [11](#)

courier font, meaning of [8](#)

E

Enterprise Network Management

configuration wizard. [23](#)

defined. [13](#)

pre-installation tasks [17](#)

Enterprise Network Management CDs

defined. [13](#)

F

feedback about this book [12](#)

H

HP OpenView

Network Node Manager [46](#)

Smart Plug In. [20](#)

HP OpenView Network Node Manager [20](#)

I

Installation

with database already installed [51](#)

installation

Administration Tools CD [28](#)

Windows server [48](#), [54](#)

installation CD

Network Management [20](#)

Network Provisioning [35](#)

IP address

changing launch page links after application

is installed. [26](#)

IP-Network-Region Form [58](#)

M

Mailbox Manager

defined [63](#)

launching [63](#)

licensing [64](#)

Microsoft SQL 2000 Database. [44](#)

N

Network Management CD

applications [19](#)

device managers [19](#)

O

OpenSSH SCP Server [28](#)

P

prerequisites, for installing [7](#)

Provisioning and Installation Manager

applications on CD [35](#)

defined [33](#)

gateways supported [33](#)

pre-installation tasks. [34](#)

Index

R

- requirements
 - Windows client [16](#)
 - Windows server [14](#), [45](#)
- resources
 - Avaya Communications, Solutions, and Integration (CSI) Group of Software Services . . . [8](#)
 - Avaya Network Management Software Systems Support Group (NMSSS) [9](#)
 - Avaya Technical Service Organization (TSO). . . . [9](#)
 - Avaya Technology and Consulting (ATAC) [8](#)
 - Customized Management Solutions for Avaya Integrated Management [10](#)
- RTCP monitor [40](#)

S

- Simple Network Management Protocol Agent [14](#)
- SNMP agent. [39](#), [45](#)
 - see if it is running [43](#)
- System -Parameters IP-Options Form [59](#)

T

- typographical conventions. [8](#)

V

- VoIP Monitoring Manager
 - defined [39](#)
 - pre-installation tasks. [42](#), [56](#)
- VoIP Monitoring Manager CD [44](#)

W

- Web Client [41](#)
- WebLM License Server [41](#), [55](#)